

SUBJECT: 440Express™ Micro-Pinhole Eliminator

The following revisions were made to the Product Information Sheet regarding the use with waterborne primers.

NOTE: When using waterborne primers, allow 440 Express to dry for 15-20 minutes. Finish by sanding with 320 or finer sandpaper, then follow your waterborne coating manufacturers' recommendations.

NOTE: If excess 440Express builds up on the repair area, allow to dry 15-20 minutes, then lightly sand with 320 grit or finer sandpaper to remove any excess product prior to applying primer. For additional information on application techniques go to [ITW Evercoat](#) on YouTube.

Please advise your customers using waterborne primers to follow the above recommendations.