

SUBJECT: Solvents over Polyester Fillers / Putties

The use of slower flashing solvents directly over sanded or un-sanded Evercoat filler and/or putty are **NOT** recommended or condoned. The application of these slow-evaporating solvents over a sanded polyester filler or putty to check for quality of repair or surface straightness / alignment can cause potential absorption. Such materials may include, but are not limited to, Wax and Grease Removers, Urethane Reducers, or Gloss Simulators such as Like90 Quick Check™.

If a solvent is required to aid with surface cleaning or dust removal, only fast-evaporating solvents such acetone or alcohol are recommended.