

# EVERCOAT®

**NEW**

## **SUPER BUILD 4:1**

**ULTRA HIGH BUILD POLYESTER PRIMER SURFACER**

**TWICE THE FILM BUILD OF OTHER  
POLYESTER PRIMERS!**

- Direct to Metal application eliminates the need for epoxy or self-etch primers
- Easy, accurate mixing without a scale
- Sprays with less overspray than traditional polyester primers



**Part No.  
100733**



**Part No.  
100730**

# SUPER BUILD 4:1

## ULTRA HIGH BUILD POLYESTER PRIMER SURFACER

### MIXING:



#730 SuperBuild 4:1

+



#733 4:1 Catalyst

- Shake and stir thoroughly before mixing.
- Mix thoroughly before pouring primer into gun cup
- Pot life is 60 minutes @ 75°F (24°C); pot life decreases at higher temperatures
- Do not leave product in the spray gun for longer than 45 minutes

### APPLICATION:

- Use a primer gun with a 1.6 to 2.2 fluid nozzle/air cap
- Adjust air pressure to 40-45psi for conventional guns or 10 psi at the cap for HVLP
- Apply 2 – 3 medium wet coats allowing 5 – 10 minutes flash time between coats

### FINISH:

- Super Build 4:1 is ready to sand in about 2 hours, depending on film build
  - Force Dry – Bake 30 minutes @ 140°F (60°C)
- Once dry, sand Super Build 4:1 with 180-400 grit sandpaper prior to next step

### TECHNICAL

#### DATA:

Appearance	Gray liquid
VOC	Packaged: 2.02 lbs/gal (243g/L) Applied: 1.51 lbs/gal (180.9g/L)
Wet-Film-Thickness (WFT)	8.0 - 10.0 mils per coat
Dry-Film-Thickness (DFT)	6.0 – 8.0 mils per coat
Solids by Volume	65 – 70%
Solids by weight	70 – 75%
Viscosity (ready to spray)	30 – 35 seconds in Zahn #3
Coverage at 1 mil 100% Transfer	1200 sq. ft. per US gallon

# EVERCOAT®

Evercoat | a division of Illinois Tool Works Inc. | 6600 Cornell Road | Cincinnati, OH 45242 | (513) 489-7600  
Made and Printed in the U.S. | ©2010 Evercoat

[evercoat.com](http://evercoat.com)