

**PRODUCT:****PART****NUMBER:**

100490	½ Gallon	4 units per case
100495	1 Gallon	4 units per case
100497	3 Gallon pail	1 unit per case

**DESCRIPTION:**

Quantum1 Large Repairs is Evercoat's first single step body repair technology specifically designed for large, multi-panel or vertical panel repairs. Its non-sag formula is specially engineered to have excellent filling properties, while eliminating the need for finishing putty. Quantum1 utilizes patent pending 10:1 technology that is the successful integration of polyester and epoxy chemistries. As a result, Quantum1 has less shrinkage, better sandability and better repair holdout than traditional body fillers and putties. Quantum1 also passes 500 hours salt spray (ASTM B117) and is compatible with HAPS-compliant and waterborne coatings.

**Use with Quantum 10:1 BPO Catalyst (#455/457/458) only!**


**FEATURES &  
BENEFITS:**

Feature/Advantages	Benefit
Eliminates finishing putty from the repair process	Saves time and money by simplifying the repair process and using less sandpaper
Easy sanding due to patent-pending 10:1 technology	Saves time by eliminating coarse grit sand scratches that need to be removed prior to applying primer.
Non-sag formula with improved vertical hold	Saves time by achieving proper fill in less applications.
Catalyst available in multiple speeds!	Eliminates need to adjust mix ratio "on the fly" as weather changes reducing the risk of repair defects due to inconsistent mix ratio.


**APPROVED  
SUBSTRATES:**

- Steel
- Galvanized Steel
- Aluminum
- SMC
- Fiberglass (cosmetic repairs only)
- Sanded OEM Paint


**NOTE: For structural repairs prone to high degrees of stress and flexibility, use a fiber reinforced filler such as Everglass®, Kitty Hair® or Fiber Tech®.**

**PREPARATION:**

- Clean and degrease the entire panel to be repaired with soap and water, followed by wax and grease remover or a cleaning solvent. Thoroughly dry surface before repairing.
- Keep the repair area small. Sand the repair area with 80 grit sandpaper, removing the paint.
- Use 180 grit sandpaper to featheredge the paint.

**MIXING:**

- Stir the body repair material before using. Knead the Quantum 10:1 BPO Catalyst tube (#455/#457/#458 sold separately).
- Measure catalyst 10% by volume  
Examples:



- Fold catalyst into material until uniform color is achieved.

**Approximate setting time is 3-4 minutes @ 72°F (22°C)**

**NOTE: Evercoat #1249 Plastik Honey CAN NOT be used with Quantum1**

**APPLICATION:**

- Apply in thin layers and spread smoothly from edge-to-edge over the entire repair area. Do not blob on or apply all at once as this causes pinholes. To ensure best adhesion apply firm pressure with spreader when applying.

**FINISH:**

- Sandable in approximately 10-12 minutes at 72°F/22°C. Sand hardened material with 180 grit sandpaper.
- DA sand and featheredge with 180 grit or finer. This will provide a smoother finish and reduce the number of coats of primer required for a quality finish.

**TECHNICAL SPECIFICATIONS:**

▪ Appearance	Off-White paste
▪ VOC	Refer to Section 9 of the Safety Data Sheet
▪ Relative Density	Refer to Section 9 of the Safety Data Sheet
▪ Sand Time	10-12 min.
▪ Max Recommended Thickness (sanded)	1/4 inch (6mm)

**NOTE:**

**Properties are typical values and should not be considered as sales specifications.  
Physical testing performed @ ~72°F (22°C) / 75% RH unless otherwise noted.**

**SAFETY &  
HANDLING:**

Read all directions and warnings prior to using Evercoat products.  
Safety Data Sheets can be found online at [www.evercoat.com](http://www.evercoat.com).

**NOTES:**

Never return mixed filler to container  
Keep container closed and store in a cool dry place

***Use with Quantum 10:1 BPO Catalyst (#455/457/458) only!***